



## REMOTE INTERFACE SPECIFICATIONS

### **ACC 060-MCD**

**Remote Reset Switch Assembly** – Momentary switch used to reset refrigerant monitor via external reset connections.

**Electrical:**

Requires no power. Connect Reset and GND terminals on ACC 060-MCD to reset and GND terminals on IR-SNIF-MCD (Terminal board 3, terminals 4 and 5).

**Physical:**

7" h x 7" w x 4.5" d (nominal).

