



IR-SNIF Series

PARTS LIST FOR OPERATION MAINTENANCE

<u>Part Number</u>	<u>Description</u>
410018	Fan Filter (IR-SNIF Series A Only)
420108	WISA Pump Springs (4)
410136	Orifice .010
410144	Coarse Filter
410162	5 Micron Filter Replacement
410224	Diaphragm Pump

COMMONLY ORDERED PARTS FOR TWO (2) YEARS OF MAINTENANCE

- 410162 5 Micron Filter Replacement – Filter is normally white. If the filter turns gray it needs changed. Recommend a change of this filter every six (6) months or if needed.
- 410144 Coarse Filter – Coarse filters (brass) are located at the end of each sampling point (zone). Coarse Filters should be checked and changed on a quarterly basis depending on environmental conditions. Replace one (1) filter for each of the monitor’s sampling points (zones) and the fresh-air intake.

Example: Two (2) Year Supply for one (1) 8 ZONE Refrigerant Monitor.

410162 5 Micron Filter Replacement 2 changes (x) 2yrs = 4 filters

410144 Coarse Filters 4 changes (x) 9 (Eight Zones plus fresh air) (x) 2 yrs = 72 filters